



Instruction of Print Head Disassembly

Step 1 : Push both forks of TPH module equally to remove the TPH module out of the linkage



Ste 2 : Disconnect the TPH cable after the TPH is removed from the linkage.



Reverse the steps above to install the new TPH module back



Note : During disassembly and installation , please be aware of the print head .